



ROTATE CROWN ADAPTER TO ALIGN WIDE GROOVE WITH ROLLER'S WIDE RAIL
 PUSH IN UNTIL ROLLER STOP BY CROWN ADAPTER'S FLANGE

NOTE: CROWN ADAPTER MUST BE SEATED PROPERLY IN ROLLER TUBE
 TO TRACK THE UPPER & LOWER LIMITS.

REVISION B - 07/31/06
 USE EXTRUDED ALUM. TUBE

VUTEC CORPORATION

2741 N.E. 4th AVENUE, POMPANO BEACH, FL 33064

DRAWN BY 04/29/05 HN	DESCRIPTION MOTOR & ROLLER ASSEMBLY ARTSCREEN - MOTOR	DRAWING NO. CROWN-ADAPTER_3DB
CHECKED BY		SCALE: 1/4 REV B